


NOTES

1. FORM SIDEWALK WITH WOOD OR METAL FRAMES. MATCH EXISTING WIDTH. IF WIDTH IS GREATER THAN 6'-0", PLACE A CONTROL JOINT AT MID WIDTH, RUNNING THE LENGTH OF THE SIDEWALK.
2. PLACE ASPHALT IMPREGNATED JOINT MATERIAL BETWEEN NEW CONCRETE AND EXISTING, OR AT ALL COLD JOINTS.
3. TOOL IN CONTROL JOINTS @ 4'-0" O.C., FULL FROM ONE SIDE TO THE OTHER. AFTER CURE, SAW CUT THESE JOINTS TO 2" DEEP.
4. CONCRETE TRUCKS SHALL BE REJECTED ONCE 2 HOURS HAVE ELAPSED FROM THE START OF MIXING AS PRINTED ON THE BATCH TICKET.
5. WWF MESH SHALL BE PULLED UP DURING PLACEMENT SO THAT IT IS IN THE MID-HEIGHT OF THE SLAB.
6. SCREED THE SIDEWALK WITH A MAGNESIUM FLAT. SURFACE SHOULD BE HAND-WORKED TO ENSURE IT IS TIGHT WITH NO STONE AT THE TOP.
7. SEAL CONCRETE WITH A SPRAY-ON SEALER.



Revisions	Date

Drawing Title	
DETAILS	
Approved: Chief Engineer	Date
Approved: Medical Center Director	Date

Project Title		
PROVIDE SITE IMPROVEMENTS		
<hr/>		
Building No.	Checked	Drawn
CAMPUS	JY	JY
<hr/>		
Location		
CANANDAIGUA, NEW YORK		

Date	4/16/2014
Project No.	528A5-14-584
Dwg.	5 Of 5

